



40 DCNF 12
Part Number:
18950.060

PARTS LIST
40 DCNF 12 – PART NO. 18950.060

| Dia No. | Qty. Req'd | Description | Part Number | Qty. Req'd | Description | Part Number |
|---|------------|-----------------------|--------------|------------|-------------------------------|-------------|
| 1 | 1 | Carburetor Top Cover | 31716.082 | 41 | Bearing Cover | 58000.01 |
| 2 | 4 | Stud | 64955.007 | 42 | Spacer Bushing | 12750.05 |
| 3 | 1 | Top Cover Gasket | 41705.029 | 43 | Spring Washer | 55530.01 |
| 4 | 1 | Choke Control Rod | 61280.056 | 44 | Throttle Return Spring | 47610.02 |
| 5 | 1 | Split Pin | 32610.005 | 45 | Throttle Control Lever | 45041.04 |
| 6 | 1 | Float Pin | 52000.010 | 46 | Idle Mixture Screw | 64755.00 |
| 7 | 1 | Screw | 64700.012 | 47 | Idle Mixture Screw Spring | 47600.00 |
| 8 | 1 | Needle Valve 'O' Ring | 83102.070 | 48 | Throttle Stop Screw Spring | 47600.00 |
| 9 | 1 | Bushing | 12775.010 | 49 | Bushing | 12785.08 |
| 10 | 1 | Needle Valve | 79903.* | 50 | Throttle Stop Screw | 64625.01 |
| 11 | 2 | Air Corrector Jet | 77501.* | 51 | Starter Cover -Including | 32556.01 |
| 12 | 1 | Choke Control Lever | 45096.020 | 52 | -Choke Control Spindle | 10085.00 |
| 13 | 1 | Lever | Not Serviced | 53 | -Cover | 32556.01 |
| 14 | 1 | Screw | 64615.004 | 54 | -Return Spring | 47610.04 |
| 15 | 1 | Pump Demand Valve | 79706.050 | 55 | -Choke Lever | 45025.08 |
| 16 | 2 | Emulsion Tube | 61450.* | 56 | -Spring Washer | 55525.01 |
| 17 | 1 | Float | 41015.015 | 57 | -Nut | 34715.01 |
| 18 | 1 | Pump Cover | 32486.041 | 58 | Filter Gauze | 37000.01 |
| 22 | 1 | Pump Jet | 76215.* | 59 | Choke Cover Screw | 64700.00 |
| 23 | 2 | Pump Jet 'O' Ring | 41540.014 | 60 | Washer | 55510.03 |
| 24 | 2 | Main Jet | 73405.* | 61 | Main Venturi (Choke Tube) | 72129.* |
| 25 | 2 | Idle Jet | 74405.* | 62 | Auxiliary Venturi | 72129.* |
| 26 | 2 | Idle Jet 'O' Ring | 41565.002 | 63 | Starter Jet | 79695.* |
| 27 | 2 | Idle Jet Holder | 52570.006 | 64 | Starter Valve Piston | 64330.00 |
| 28 | 1 | Pump Spring | 47600.107 | 65 | Starter Valve Spring | 47600.13 |
| 29 | 1 | Pump Diaphragm | 47407.261 | 66 | Spring Guide | 12775.02 |
| 30 | 4 | Pump Cover Screw | 64700.006 | 67 | Spring Clip | 10140.00 |
| 31 | 2 | Throttle Spindle Nut | 34710.003 | 68 | Fuel Filter Inspection Cover | 61002.01 |
| 32 | 2 | Lock Washer | 55530.004 | 69 | Fuel Filter Cover Gasket | 41530.02 |
| 33 | 1 | Spacer | 12750.032 | 70 | Filter Washer | 61060.00 |
| 34 | 1 | Pump Cam | 14852.011 | 71 | Fuel Filter | 37020.00 |
| 36 | 1 | Throttle Shaft | 10005.211 | 72 | Washer | 55510.03 |
| 37 | 2 | Throttle Valve | 64005.020 | 73 | Top Cover Screw | 64700.00 |
| 38 | 4 | Throttle Valve Screw | 64530.027 | 74 | Air By-Pass Screw | 64750.00 |
| 40 | 2 | Sealed Bearing | 32650.003 | 75 | Air By-Pass Screw Locking Nut | 34705.00 |
| *Calibrated Parts Require 3 Digits To Complete Part Number. | | | | | | |
| See Calibrated Parts Section For Sizes | | | | | | |