

## Early Merak SS Electronic System Controls

1. Left headlight
2. Left turn signal
3. Left fog lamp
4. Left side light
5. Warning light for headlamp (fitted only for *Germany*)
6. Pneumatic horn compressor
7. Relay for left fan control
8. Relay for right fan control
9. Relay for cutting - out coil resistance
10. Left radiator fan
11. Radiator thermic head
12. Right radiator fan
13. Right side light
14. Right headlight
15. Right turn signal
16. Right fog lamp
17. Manometric switch for cooling compressor control
18. Front left brake pad with wear contact
19. Front right brake pad with wear contact
20. Motor for engine compartment heating fan
21. Baggage compartment lamp
22. Windshield wiper timer
23. Windshield wiper motor
24. Windshield washer motor
25. Switch for insufficient brake oil pressure signaling
26. Relay for passenger compartment fan
27. Relay for pneumatic horn control
28. Fog lamp relay
29. Stop light switch
30. Brake balancing switch
31. Warning light for parking lamps
32. Glove box lamp
33. Radio antenna
34. Semiconductor for cooling system
35. Intermittence for turn signals and HAZARD lights
36. Relay for headlight high beam control

37. Relay for headlight low beam control
38. Emergency switch for parking lights
39. Fuel level and warning light for fuel reserve
40. Electric control switch for radio antenna
41. Passenger compartment lamp switch
42. Rear window defroster switch
43. Cooling system switch
44. Cooling system control thermostat
45. Dashboard lamp
46. Radio
47. Headlights commutators unit
48. Commutator unit for turn signals, headlamp, and horns
49. Windshield wiper and washer unit switch
50. Revolution counter (tachometer)
51. Warning light for insufficient brake oil pressure with button for warning light test
52. Engine oil pressure gauge
53. Speedometer and tachometer
54. Starting switch
55. Starting switch lamp
56. Fog light switch
57. Emergency HAZARD parking light switch
58. Warning light for connected handbrake
59. Water temperature gauge
60. Rear window warning light
61. Engine oil temperature gauge
62. Warning light for lifted headlamp (Germany only)
63. Voltmeter
64. Warning light for brake balancing or pad wear
65. Electronic clock
66. Rheostat for dashboard instrument lights
67. Commutator for passenger compartment fan
68. Left door window switch
69. Right door window switch
70. Cigarette lighter
71. Light for cigarette lighter
72. Left door switch
73. Left door window motor

74. Left door - open warning light
75. Handbrake switch
76. Left loudspeaker
77. Right loudspeaker
78. Thermic rear window
79. Drivers compartment light
80. Right door switch
81. Right door window motor
82. Right door - open warning light
83. Alternator tension governor
84. Float for fuel level indicator
85. Bulb for engine oil temperature
86. Bulb for engine oil pressure
87. Bulb of engine water overheating warning light
88. Bulb for engine water temperature
89. Fuel pump
90. Battery
91. Engine compartment - left lamp
92. Rear left light cluster
93. Alternator
94. Starter motor
95. Left side license plate lamp
96. Right side license plate lamp
97. Electromagnetic fan clutch for AC compressor
98. Rear red fog light
99. Reverse light switch
- 100 Distributor
- 101 Distributor connection
- 102 Ignition coil left side
- 103 Ignition coil amplifier - left side
- 104 Ignition coil amplifier - right side
- 105 Ignition coil right side
- 106 Engine compartment - right lamp
- 107 Rear right light cluster